

T15 FIRMWARE UPDATE


Follow the T15 User Guide for full guidance to operate the T15.

CHECK YOUR CURRENT T15 VERSION

Press the power button for 1 second to power the T15 on. A splash screen will appear followed by the thermal display.

Depress the mode button for 5 seconds to open the T15 menu and Select '**Version**'.

Note the T15 Version, i.e. **V1.1.2-74**. Confirm the downloaded firmware version is newer than the current firmware version, i.e. **V1.2.2-23**.




UPGRADE T15 FIRMWARE

Press the power button for 1 second to power the T15 on. A splash screen will appear followed by the thermal display.

Depress the mode button for 5 seconds to open the T15 menu and Select '**Version**'.



Select '**Allow Update**' to begin a firmware update process. A MAC or PC with the updated firmware file is required.



Connect the T15 to a PC or MAC with the supplied USB cable while the T15 is on the UPDATE screen.




To PC / Mac



NOTE: The only way to exit the UPDATE screen is to Shutdown the unit and power the unit back on.

While the T15 is connected to a PC/MAC in the update mode, the T15 will mount to the computer like an SD card as 'T15 Drive'.

Download the new T15 firmware file and copy the file into the 'T15 Drive' directory.



After the update file is loaded into the above 'T15 Drive' directory, the T15 screen indicates an 'Update' option. Select 'Update' to begin. A 'Success' update status message appears when complete.



Select Shutdown and power the T15 back on to finish the update.

